

Field Hydrogeology, 4th Edition

By Rick Brassington

Table of Contents

Preface, Acknowledgements

1 Introduction

- 1.1 Groundwater Systems
- 1.2 Conceptual Model
- 1.3 Groundwater Computer Modelling
- 1.4 Hydrogeological Report Writing
- 1.5 Expert Witness

2 Desk Study

- 2.1 Defining the Area
- 2.2 Identifying the Aquifers
- 2.3 Groundwater Levels
- 2.4 Surface Water
- 2.5 Recharge
- 2.6 Groundwater Use
- 2.7 Groundwater Chemistry
- 2.8 Aerial Photographs and Satellite Imagery
- 2.9 Planning a Fieldwork Programme

3 Field Evaluation of Aquifers

- 3.1 Grain Size Analysis
- 3.2 Hydraulic Properties of Aquifers
- 3.3 Hydraulic Properties and Rock Types
- 3.4 Assessing Hydraulic Properties
- 3.5 Using Hydraulic Property Information

4 Groundwater Levels

- 4.1 Water-Level Dippers
- 4.2 Continuous Water-Level Recorders
- 4.3 Measuring Ground Levels and Locations
- 4.4 Tool-Box
- 4.5 Well Catalogue
- 4.6 Field Surveys for Wells, Boreholes and Springs
- 4.7 Interpretation of Abstraction Borehole Water Levels
- 4.8 Groundwater-Level Monitoring Networks
- 4.9 Groundwater-Level Fluctuations
- 4.10 Managing Groundwater-Level Data
- 4.11 Constructing Groundwater Contour Maps and Flow Nets
- 4.12 Interpretation of Contour Maps and Flow Nets
- 4.13 Using Other Groundwater Information

5 Rainfall, Springs and Streams

- 5.1 Precipitation
- 5.2 Evaporation
- 5.3 Springs
- 5.4 Stream-Flow Measurement
- 5.5 Stage-Discharge Relationships
- 5.6 Choosing the Best Method
- 5.7 Processing Flow Data

6 Pumping Tests

- 6.1 What Is a Pumping Test?
- 6.2 Planning a Pumping Test
- 6.3 Pumps and Pumping
- 6.4 On-Site Measurements
- 6.5 Pre-Test Monitoring

- 6.6 Test Set-up
- 6.7 Step Tests
- 6.8 Constant Rate Tests
- 6.9 Recovery Tests
- 6.10 Pumping Test Analysis
- 6.11 Tests on Single Boreholes
- 6.12 Packer Tests

7 Groundwater Chemistry

- 7.1 Analytical Suites and Determinands
- 7.2 Sampling Equipment
- 7.3 Sampling Protocols
- 7.4 Monitoring Networks
- 7.5 Using Chemical Data

8 Recharge Estimation

- 8.1 Water Balance
- 8.2 Rainfall Recharge
- 8.3 Induced Recharge
- 8.4 Other Sources of Recharge

9 Specialist Techniques

- 9.1 Borehole and Piezometer Installation
- 9.2 Down-Hole Geophysics
- 9.3 Using Artificial Tracers

10 Practical Applications

- 10.1 Borehole Prognoses
- 10.2 Groundwater Supplies
- 10.3 Wells in Shallow Aquifers
- 10.4 Contaminated Land Investigations
- 10.5 Landfills and Leachate
- 10.6 Geothermal Energy
- 10.7 Groundwater Lowering by Excavation
- 10.8 Rising Water Tables
- 10.9 Soakaways
- 10.10 Investigating Wetland Hydrology

A. Good Working Practice

- A1.1 Safety Codes
- A1.2 Safety Clothing and Equipment
- A1.3 Distress Signals
- A1.4 Exposure or Hypothermia
- A1.5 Heat Exhaustion
- A1.6 Working Near Wells, Boreholes and Monitoring Piezometers
- A1.7 Hygiene Precautions for Water Supplies
- A1.8 Trial Pits
- A1.9 Electrical Equipment
- A1.10 Filling Fuel Tanks
- A1.11 Waste Disposal Sites
- A1.12 Stream Flow Measurement

B. Conversion Factors

References and Further Reading; Index